To Replace Batteries and Install Battery-Pack:

Requires 4 AA 1.5 V Batteries (sold separately)

Battery removal and replacement must be done by adult only.

• Non-rechargeable batteries are not to be recharged • Different types of batteries or new and used batteries are not to be mixed • Batteries are not to be placed near open flame or heat • Batteries are to be inserted with the correct polarity • Exhausted batteries are to be removed from the toy • The supply terminals are not to be short-circuited • Rechargeable batteries are only to be charged under adult supervision • **DISPOSAL** – This product contains batteries and electronics that may be harmful to the environment; they should not be discarded with normal household waste but taken to your local collection center for recycling. • Please retain this information for future reference.



1. Remove lid from battery pack.

2. Place 4 AA 1.5V batteries into pack with correct polarity and replace the lid.



3. Connect fan to battery pack (or your own portable charging device) using the provided USB cord.



4. Place battery back into the pouch provided on the costume.

THE FAN HAS BEEN PRE-INSTALLED INSIDE THE COSTUME.

To Re-Install the Fan in-case it's Detatched from the Costume:



1. Locate round opening on outside of costume. Place mechanism inside of costume, bringing round fan through opening.

2. Screw outer fan ring into place to secure fan to costume.



3. Move battery pack switch to **ON** position. Step into costume. Place battery pack inside pocket provided within the costume.

4. Secure all openings so air does not escape from costume. After taking off costume, switch battery pack to **OFF** position and remove batteries.

Placing the Costume Hood:

IF APPLICABLE. For Some Costume Styles Which Have "Open Face" Designs, Place the Costume Hood under Following Instructions:

1. Pull your head through the elastic neckline and adjust the velcro.

2. Put on the costume head like a hoodie.

3. Inflate the costume.

DO NOT leave the elastic neckline around your face. This will result in the costume head hanging on the back of your head.